RAPTOR-C19 SIM Card Guidance for Samsung Tab A

Before attempting to use the SIM cards please power off your device.

1) Use the metal tool that came with the tablet to gently open the SIM tray. The tool can be found on the inside of the box the tablet came in.
2) Pull out the tray and inset the SIM card before closing the tray, ensuring the tray has locked in place.
3) Restart your device.
4) Go into the Wiifi settings and disconnect the tablet from the practice Wifi.
5) Your tablet will now use cellular data.



If you have any issues please contact the team at RAPTOR@phc.ox.ac.uk